

# ADDENDA

## FLYBALL MANUAL MISPRINT

On page 15 of the Flyball manual, left-hand column, Table 4-1 top.

Switch #1	}	Not used (can be any position) Game length is 1 inning when in "off" position; 2 innings when in "on" position.
Switch #2		
Switch #3		

Should be:

Switch #1	}	Not used (can be in any position) Game length is 1 inning when in "on" position; 2 innings when in "off" position.
Switch #2		
Switch #3		

On schematic sheet 7 of 9 pages, power supply:

- a. Parallel a 4 ohm 10 watt resistor across R62.
- b. Parallel a 8000 uf/16 volt capacitor across C41 .

Please make sure the above is also done to the game printed circuit board.

## SPARE PARTS LIST

GAME NAME LeMans

\*Critical Parts

ITEM	PART NUMBER	QTY.	DESCRIPTION
	37-3400	4	IC 7400
2	37-7402	3	IC 7402
3	37-7404	3	IC 7404
4	37-74504	1	IC 74504
5	37-7406	1	IC 7406
6	37-7408	2	IC 7408
7	37-7410	2	IC 7410
8	37-7413	1	IC 7413
9	37-7427	1	IC 7427
10	37-7442	1	IC 7442
11	37-7474	8	IC 7474
12	37-7486	1	IC 7486
13	37-7493	3	IC 7493
14	37-74107	2	IC 74107
15	37-74153	2	IC 75153
16	37-74164	1	IC 74164
17	37-74165	2	IC 74165
18	37-74192	1	IC 74192
19	37-74193	2	IC 74193
20	37-555	1	IC 555
21	37-566	2	IC 566
22	37-LM309	1	IC LM309K
23	37-LM324	1	IC LM324
24	37-LM380	1	IC LM380
25	37-9314	2	IC 9314
26	37-9316	4	IC 9316
27	37-9321	1	IC 9321
28	37-9322	1	IC 9322

## SPARE PARTS LIST

GAME NAME

\*Critical Parts

[illegible]

LEMANS SPARE PARTS

A000598-03	Steering Assy. (includes A000607)	1
A000608-01	Shift Assy.	1
A004304-07	Start Switch	1
A004798	Foot Pedal Assy.	2
001551-1	X - Former	1

PCB ASSEMBLY

A005844